USER'S MANUAL

Made in China

M1010400966

USER'S MANUAL



Digital Clamp Meter

Please read this manual carefully before using the product and keep it properly for future reference.

120*90mm

Safety Information

Introduction

This meter is a handheld true-RMS(Root mean square) digital clamp meter designed for current measurement and RCD/ LCD line impedance automatic voltage identification, inrush current measurement frequency measurement, capacitance measurement, diode measurement, temperature measurement of various electrical parameters, making it an ideal tool for power maintenance, electrical installation, industrial testing and other fields. It can measure AC/DC voltage, AC/DC current, resistance, diode, continuity test, resistance, capacitance, diode, continuity, frequency, and temperature. It also includes functions like NCV, Max/ Min, HOLD, Relative, Backlight, Auto power off, and Low battery prompt. Moreover, this safety product and its a

1. Safety information

- Please read the following carefully before the use of the meter. Strictly operation can avoid the electric shock or damage to it. Please read the manual carefully before use and follow the instructions.

- Do not measure the voltage above the rated voltage between terminals or between one terminal and the ground, to avoid damage to the meter.

- Before use, ensure the meter is working properly, the insulation layer of the test probes is undamaged. No battery cover is closed and the battery power is sufficient. Otherwise, it may cause inaccurate measurement.

- Don't exceed the maximum measurement range of meter for gear during measurement.

- Please keep your fingers behind protect parts when the meter is connected to a measuring circuit.

Marks	Description
⏦	AC voltage
⎓	DC voltage
⚠	Caution, risk of danger, refer to the manual.
⏚	Earth (ground)
⧈	Double insulation
CAT III	Overvoltage (installation) category III
CAT IV	Overvoltage (installation) level according to IEC61010 standard

Device

* Operate carefully in measuring voltages above DC 60V or AC 30V. Such voltages pose a shock hazard to users. Keep your fingers behind the barrier or the test probe from the circuit when energizing the measurement function.

* Before changing measure, confirm, please remove the test probe from the circuit and turn off the power supply.

* Before measuring resistance, continuity, diode, or capacitance, disconnect the circuit power and fully discharge the circuit under test and discharge all high-voltage capacitors.

* Do not use the clamp to measure AC/DC currents over 1000A.

Device

3.Symbols

Symbols	Description
AUTO	Automatic measuring range
MANU	Manual measuring range
SELECT	Select the measuring function
REL	Relative value
MAX	Maximum value
MIN	Minimum value
HOLD	Data hold
⏦	AC voltage
⎓	DC voltage
Hz	Frequency
LPF	Variable-frequency measurement
Ω	Resistance
⏚	Continuity
⊣⊢	Capacitance
⊣◁	Diode
°C	Unit of temperature
°F	Unit of temperature
nF	Unit of capacitance
μF	Unit of capacitance
mF	Unit of capacitance
A	Unit of current
V	Unit of voltage
Ω	Unit of resistance
Hz	Unit of frequency
NCV	Non-contact voltage detection

Button Introduction

3.2 Buttons

Buttons	Description
SEL	Function selection
RANGE	Manual/automatic value
ZERO	Zero adjustment
HOLD/LPF	Data hold/Variable-frequency measurement
HOLD ⏻	Data hold/Backlight

3.3 Input terminal

Input terminal	Description
COM terminal	Connect with the black probe.
INPUT terminal	Connect with the red probe.

Technical parameters

4. Technical parameters

Automatic measuring range	Yes
4 digit counter display maximum reading	6000
Update rate (4 times/ second)	400 milliseconds/ Hz
Auto-shutdown time	About 15 minutes
Backlight auto-off	About 2 minutes
Backlight auto-off	About 15 minutes
Power Supply	2x1.5v mini-batteries
Operating temperature	41~104 F
Storage temperature	-14~ ~ 851
Dimension	210mm(19mm)x70mm
size less	20mm
Weight	about 440g (Without battery)

Functions

5. Functions

- NCV, button, pulse into NCV.Low, "---", , resistance/continuity/diode/open loops, AC/DC voltage, AC/DC current.

- Measure AC/DC current, AC/DC current clamp size is AC voltage(0~ voltage(DC) DC mode, and press NCV / SEL / LO cancel the NCV / SEL / LO(Low) in AC mode, press and hold the ZERO button for more than 2 seconds to enter the relative value mode, and the meter will display the relative value current caused by the magnetic field interference in the zero-current state, and subtract the relative value from the measurement value.

- LPF button: Short LPF(Variable-frequency measurement) in AC voltage measurement mode, and press and hold for more than 2 seconds to enter the measurement results. This reverses diode and accurate measurement of variable-frequency voltage or current, even in the presence of high-frequency interference.

- MAN/Auto button: To measure the peak value, Pressing the key toggle where the power is on, press and hold the ZERO button in AC current measurement mode to enter the relative value mode, and the meter will display zero. Disconnect the power to exit mode, Hold the key for more than 2 seconds to enter the peak mode, and the meter will display the peak value of the current. Press and hold the button to exit the peak mode.

- Backlight button: Press the button to turn on the backlight, and the backlight will automatically turn off after 15 seconds. The backlight will automatically light up. When the low voltage reminder is displayed, the backlight will not be turned on.

- Auto-shutdown function: The meter automatically enters sleep mode after 15 minutes of inactivity. To wake it up, simply press any button. To cancel the auto-shutdown function: Turn the rotary switch to OFF, then press and hold the SEL button while turning the switch to any position to exit the meter will exit sleep mode and one short beep, indicating that the auto-shutdown function can be cancelled. Note that the auto-shutdown function is disabled by default each time the meter is powered on.

- Battery undervoltage indication: Battery undervoltage indication: When "" appears on the screen, it indicates that the battery is low. Please replace the battery promptly to ensure the accuracy of the battery in the measurement results. This ensures stable and accurate measurement of variable-frequency voltage or current, even in the presence of high-frequency interference.

- HOLD button: To measure the peak value, Pressing the key toggle where the power is on, press and hold the ZERO button in AC current measurement mode to enter the relative value mode, and the meter will display zero. Disconnect the power to exit mode, Hold the key for more than 2 seconds to enter the peak mode, and the meter will display the peak value of the current. Press and hold the button to exit the peak mode.

- Backlight button: Press the button to turn on the backlight, and the backlight will automatically light up. When the low voltage reminder is displayed, the backlight will not be turned on.

- Auto-shutdown function: The meter automatically enters sleep mode after 15 minutes of inactivity. To wake it up, simply press any button. To cancel the auto-shutdown function: Turn the rotary switch to OFF, then press and hold the SEL button while turning the switch to any position to exit the meter will exit sleep mode and one short beep, indicating that the auto-shutdown function can be cancelled. Note that the auto-shutdown function is disabled by default each time the meter is powered on.

- Battery undervoltage indication: Battery undervoltage indication: When "" appears on the screen, it indicates that the battery is low. Please replace the battery promptly to ensure the accuracy of the battery in the measurement results. This ensures stable and accurate measurement of variable-frequency voltage or current, even in the presence of high-frequency interference.

- HOLD button: To measure the peak value, Pressing the key toggle where the power is on, press and hold the ZERO button in AC current measurement mode to enter the relative value mode, and the meter will display zero. Disconnect the power to exit mode, Hold the key for more than 2 seconds to enter the peak mode, and the meter will display the peak value of the current. Press and hold the button to exit the peak mode.

How to Use

6.1 How to Use

(1) Turn the switch to the ⏦ position, the screen shows that ⏦ and the meter is in the AC voltage measurement mode.

(2) Insert the red test probe into the VΩ terminal, the red probe is connected to the INPUT terminal, and the red test probe is connected to the VΩ terminal, the black probe is connected to the COM terminal, the meter displays the voltage value of the circuit under test.

6.2 DC voltage

(1) Turn the switch to the ⎓ position, the screen shows that ⎓ and the meter is in the DC voltage measurement mode.

(2) Insert the red test probe into the VΩ terminal, the red probe is connected to the INPUT terminal, and the red test probe is connected to the VΩ terminal, the black probe is connected to the COM terminal, the meter displays the voltage value of the circuit under test.

6.3 AC current

(1) Turn the switch to the ⏦ position, press SEL button, to switch to the AC current measurement mode, and the meter will display the A.

(2) Press the trigger and open the jaw, clamp the wire to be measured with the single conductor in the center of the jaw, release the trigger and close the jaw tightly, and place the single wire covered with in the axis of the jaw as much as possible to measure the current of the circuit under test, the meter displays the current value of the circuit under test.

6.4 AUTO+LOZ low impedance AC/DC voltage automatic identification function

(1) Turn the rotary switch to the AUTO+LOZ position, and the screen shows that NCV, the meter is in the AUTO+LOZ low impedance AC/DC voltage measurement mode, and the meter is in the AC voltage mode by default, the voltage up to AC 12V, according to the measured voltage display.

(2) The test probe is connected to the "COM" terminal, the red probe is connected to the "INPUT" terminal, and the red and black probes are connected in the circuit to be measured, the screen displays the voltage value of the circuit under test.

6.4 AC/DC

(1) Turn the switch to the ⏦ position, press SEL button, to switch to the AC voltage measurement mode, and the meter will display the V.

(2) Insert the red test probe into the VΩ terminal, the red probe is connected to the INPUT terminal, and the red test probe is connected to the VΩ terminal, the black probe is connected to the COM terminal, the meter displays the voltage value of the circuit under test.

6.5 DC current

(1) Turn the switch to the ⎓ position, press SEL button, to switch to the DC current measurement mode, and the meter will display the A.

(2) Press the trigger and open the jaw, clamp the wire to be measured with the single conductor in the center of the jaw, release the trigger and close the jaw tightly, and place the single wire covered with in the axis of the jaw as much as possible to measure the current of the circuit under test, the meter displays the current value of the circuit under test.

6.6 Resistance

(1) Turn the switch to the Ω position, the screen shows that Ω and the meter is in resistance measurement mode.

(2) Insert the red test probe into the VΩ terminal, the red probe is connected to the INPUT terminal, and the red test probe is connected to the VΩ terminal, the black probe is connected to the COM terminal, the meter displays the resistance value.

Attention!

(1) When measuring resistance in the circuit, the power must be turned off and the capacitor must be discharged first, because the measured resistance is inaccurate when in parallel connection with other resistors in the circuit.

(2) When measuring resistance above 1MΩ, it takes a few seconds for the reading to stabilize, which is normal. For accurate readings, disconnect the power to the circuit under test and discharge all capacitors.

(3) When the input is not connected, i.e. at open circuit, the maximum voltage of the meter is about 3V.

(4) When the resistance is open or the resistance value exceeds the maximum range of the instrument, the meter displays the overload indication "1".

6.7 Continuity test

(1) Turn the switch to the ⏚ position.

(2) Press SEL button to switch continuity measurement mode, and the meter will display the sound.

(3) The black probe is connected to the "COM" terminal, the red probe is connected to the "INPUT" terminal, and the red and black probes are connected to the circuit for measurement.

Attention!

(1) When measuring the resistance, the capacitance, the capacitance should be discharged first and the power to the circuit should be cut off.

(2) When measuring the resistance, the red probe is connected to the positive terminal of the multimeter, and the black probe is connected to the negative terminal of the multimeter.

(3) When measuring the resistance, the screen will first display the overload value, and then the measurement value will be displayed on the screen.

How to Use

6.8 Diode

(1) Turn the switch to the ⊣◁ position.

(2) Press the SEL key to select the ⊣◁ measurement mode, and the meter will display the V.

(3) The black probe is connected to the "COM" terminal, the red probe is connected to the "INPUT" terminal, and the red and black probes are connected to the diode for measurement, and the on-voltage value of the diode is displayed on the screen.

Attention!

(1) When measuring a normal diode, the meter displays the forward voltage drop value, both probes are reversed, and the meter displays "1.OVER".

(2) The fault voltage of the diode should be between 1.0V~1.8V.

How to Use

6.9 Capacitance

(1) Turn the switch to the ⊣◁ position.

(2) Press SEL button to switch capacitance measurement mode, and the meter will display the nF.

(3) The black probe is connected to the "COM" terminal, the red probe is connected to the "INPUT" terminal, and the red and black probes are connected to the capacitor for measurement, the screen displays the measured capacitance value.

Attention!

(1) When measuring the capacitance, the capacitance should be discharged first and the power to the circuit should be cut off.

(2) When measuring the capacitance, the red probe is connected to the positive terminal of the multimeter, and the black probe is connected to the negative terminal of the multimeter.

(3) When measuring the capacitance, the screen will first display the overload value, and then the measurement value will be displayed on the screen.

How to Use

6.10 Frequency

(1) Turn the switch to the Hz position, and the meter will display Hz.

(2) The test probe is connected to the "COM" terminal, the red probe is connected to the "INPUT" terminal, and the red and black probes are connected to the measured signal source, and the frequency value is displayed on the screen.

How to Use

6.11 Temperature

(1) Turn the switch to the ℃/℉ position, the meter will automatically measure the current ambient temperature, and the current temperature value will be displayed on the screen, and the default unit is degrees Celsius.

(2) To measure the temperature of an object's head, insert the red lead of the K-type thermocouple probe into the "INPUT" terminal and the black lead into the "COM" terminal, and place the thermocouple probe in contact with the object to be measured.

How to Use

6.12 NCV noncontact AC voltage detection

(1) Turn the switch to the NCV position and the screen will display NCV. (2) Close the end (metal) with "NCV" at the top of the clamp head to the wire to be measured, and the meter will sense the voltage in the wire and the detected voltage (-ive, the screen displays (-1-) If the detected voltage is high, the screen displays (---) If the detected voltage is high, the screen displays (---) If the red backlight lights up, it indicates that the wire is live, and the meter emits different frequencies to alert you that the conductor is live.

Attention!

(1) Make sure to indicate from the meter the voltage has affected. do not rely on noncontact voltage detection to determine whether a circuit is influenced by factors such as insulated gloves, insulated boots, or insulated mats, or in a non-conductive environment (such as flashlights, rubber, plastic sheaths, or wooden handles) that trigger noncontact voltage detectors for mistakes.

How to Use

6.13 Live wire identification

(1) Turn the switch to the ⏦ position, press the SEL button to switch the live wire identification function, and the screen will display Live. (2) Touch the metal part of the test lead to the metal part of the wire to be detected, and touch the metal part of the other test lead to the ground or other neutral wire. If the wire to be detected is live, the meter will emit an alarm, the conductor being tested is a live wire. If not, it is a neutral or ground wire.

Attention!

(1) Before use, please test the meter on a known live conductor to ensure that the meter is working properly.

(2) Before using the live wire of the meter, please unplug the other electrical devices before testing it.

(3) Do not use the meter in humid, dusty, or corrosive environments.

How to Use

6.14 Inrush current measurement

(1) Turn the switch to the ⏦ position, press the SEL button to switch to the inrush current measurement mode, and the meter will display the A.

(2) Press the trigger and open the jaw, clamp the wire to be measured with the single conductor in the center of the jaw, release the trigger and close the jaw tightly, and place the single wire covered with in the axis of the jaw as much as possible to measure the current of the circuit under test, the meter displays the current value of the circuit under test.

Technical Indicators

7. Technical indicators

7.1 AC current

Range	Resolution	Accuracy
60	0.01A	±(2.5% reading +5 digits)
600	0.1A	
1000A	1A	±(3.0% reading +5 digits)

Maximum input current: 1000A

Frequency range: 50Hz~ 60Hz

7.2 Inrush current

Range	Resolution	Accuracy
60	0.01A	±(2.5% reading +5 digits)
600	0.1A	
1000A	1A	±(3.0% reading +5 digits)

7.3 DC current

Range	Resolution	Accuracy
60	0.01A	±(2.5% reading +5 digits)
600	0.1A	
1000A	1A	±(3.0% reading +5 digits)

Maximum input current: DC 1000A

7.4 AC voltage

Range	Resolution	Accuracy
6	0.001V	±(1.0% reading +3 digits)
60	0.01V	
600	0.1V	
1000V	1V	±(2.0% reading +5 digits)

Input impedance: 10MΩ, Maximum input voltage: AC 750V

Frequency response: 50Hz-1KHz

Technical Indicators

7.5 AUTO+LOZ AC voltage

Range	Resolution	Accuracy
6	0.001V	±(1.0% reading +3 digits)
60	0.01V	
600	0.1V	
1000V	1V	±(2.0% reading +5 digits)

Input impedance: 80Ω, Maximum input voltage: AC 750V

Frequency response: 50Hz-1KHz

7.6 Resistance

Range	Resolution	Accuracy
600Ω	0.1Ω	±(1.2% reading +3 digits)
6KΩ	0.001KΩ	
60KΩ	0.01KΩ	
600KΩ	0.1KΩ	
6MΩ	0.001MΩ	
60MΩ	0.01MΩ	±(2.0% reading +5 digits)

Overload protection: 600V

Technical Indicators

7.8 Continuity test

Function	Range	Description	Test condition
⏚	600Ω	Resistance value is lower than 50Ω, the buzzer will sound continuously	Open circuit voltage: about 3V

Overload protection: 600V

7.9 Diode test

Function	Range	Description	Test condition
⊣◁	2.4V	Forward DC current value of the diode	Open circuit voltage: about 3V

Overload protection: 600V

Technical Indicators

7.10 Capacitance

Range	Resolution	Accuracy
6nF	0.001nF	±(4.0% reading +10 digits)
60nF	0.01nF	
600nF	0.1nF	
6μF	0.001μF	
60μF	0.01μF	
600μF	0.1μF	
6mF	0.001mF	±(10.0% reading +10 digits)
60mF	0.01mF	

Overload protection: 600V

Technical Indicators

7.12 Frequency

Range	Resolution	Accuracy
10Hz	0.001Hz	±(1.0% reading +5 digits)
100Hz	0.01Hz	
1KHz	0.1Hz	
10KHz	0.001KHz	
100KHz	0.01KHz	
1MHz	0.1KHz	
10MHz	0.001MHz	
50MHz	0.01MHz	

Overload protection: 600V

7.13 Temperature

Range	Resolution	Accuracy
-58~1832℉	1℉	±(3.0% reading +10 digits)
-50~1000℃	1℃	

Overload protection: 600V

Battery Replacement&Maintenance

8. Battery replacement

- When [ ] appears on the screen, it means the battery is low. Please replace the battery promptly to ensure the accuracy of the measuring circuit.

1. Remove the rotary switch from the measuring circuit.
2. Use a screwdriver to remove the screw of the battery cover, and remove the battery cover.
3. Remove the battery cover.
4. Remove the old battery.
5. Install a new battery.
6. Install the battery cover and tighten the screws.

9. Accessories

1. Operation manual ×1
2. Test Lead ×1
3. Test probe ×1
4. K-type thermocouple probe ×1
5. Carrying bag ×1
6. Storage bag ×1