USERS MANUAL

Made in China

RoHS M101040058

Before using the instrument, please read this manual carefully and save it well for future using.

USERS MANUAL

Digital multimeter



120*90mm

Before using the instrument, please read this manual carefully and save it well for future using.

1.Overview

- This product is a 4000-count automatic range digital multimeter. It has the functions of 'MAX' maximum value hold, HOLD data hold, temperature measurement, capacitance measurement, NCV detection, over-load protection, backlight and battery undervoltage indication, etc. Whether used by professionals, factories, schools, their lovers or families, it is an ideal measuring instrument.
- The meter can be used to measure AC/DC voltage, AC/DC current, resistance, capacitance, diode, on/off, temperature, live wire identification, NCV detection.

2.Safety/security information

⚠	**Attention should be paid to the use of the meter. Wrong operation may cause electric shock or damage. Before using the meter, please read the following carefully and use it according to the operating instructions.**

- When using, please observe the standard safety rules.
- Upon receipt, please check whether it is damaged in transit and whether the probe is in good condition.
- If it is stored for a long time, be sure that the meter shall is damaged, the probe insulation layer is complete, and, the functional range is correct.
- It is forbidden to measure beyond the indicated value of the range protection value. Do not measure the voltage above 1000V. The meter fuse should be replaced immediately when the meter shows the " " symbol.
- The meter should be turned off after use.
- When the meter is stored for a long time, the battery should be taken out to prevent leakage and corrosion.

- Before changing the measurement function, please remove the probe from the circuit under test.

2.1 Works

⚠	Warning ! Important safety information, see the instruction manual.
⏚	Safety use to avoid danger
☐	Double insulation protection (class II).
⎓	Direct current
~	Fuse
CE	Complies with the directives of the European Union.
CAT III	Refers to the level of pulse withstand voltage protection provided by over-voltage (installation) level III and pollution degree 2 according to IEC-61010 standard.

2.2 Maintenance

- Non-professional maintenance personnel are forbidden to open the bottom case to adjust or repair the meter.
- If the meter is stored for a long time, be sure that the meter shall is damaged, the probe insulation layer is complete, and, the functional range is correct.
- It is forbidden to measure beyond the indicated value of the range protection value. Do not measure the voltage above 1000V. The meter fuse should be replaced immediately when the meter shows the " " symbol.
- The meter should be turned off after use.
- When the meter is stored for a long time, the battery should be taken out to prevent leakage and corrosion.

3. Introduction

3.1 Schematic diagram of appearance



1.Flashlight
3. NCV indicator light
5. Function keys
7. Input end
2. LCD
4. NCV non-contact AC voltage probe
6. Range knob

3.2 Description of input end

Input end	Description
COM	Common input end (connected with black probe).
VΩ⏚ ➡)))	Voltage, resistance, capacitance, temperature, diode, continuity, on/off input end (connected with red probe).
μA/mA	Current μA、mA input end (connected with red probe).
10A	Current 10A input end (connected with red probe).

3.3 Description of display symbols

Symbol	Description
BAT	Battery under-voltage
AUTO	Automatic measurement
-	Negative electrode
AC	AC voltage
DC	DC voltage
)))	On/off
➡	Diode
°C / °F	Degree Celsius/Fahrenheit degree
HOLD	Reading hold
MAX	Maximum hold
NCV	Noncontact AC voltage detection
LIVE	Live wire identification
Auto	Automatic range
Hz	Frequency
%	Percentage
Ω K M	Resistance
nF uF mF	Capacitance
uA mA A	Current

3.4 Key description

Key	Description
HOLD	Data hold
MAX	Maximum value hold
☀/🔦	Flashlight/backlight
SEL	Function selection

4.Operation guide

4.1 Data hold

(1) During measurement, short press the HOLD key to lock the measured data, and press the HOLD key again to unlock it.

4.2 MAX maximum value hold

(1) The maximum value hold can be used in AC/DC voltage, AC/DC current and resistance. Lock the maximum value of measured data, and short press it to turn the function on or off.

4.3 Flashlight/backlight

Short press the ☀/🔦 key to turn on or off the backlight, and long press the ☀/🔦 key to turn on or off the flashlight.

4.4 Temperature measurement

(1) Select the temperature function in ℃/℉ conversion.

(2) Connect the temperature probe into the COM end and the red probe into the V input end.

(3) The red and black probes contact the tested line, and the meter screen displays the measured value.

4.5 Capacitance measurement

(1) Select the appropriate position in the capacitance function.

(2) Insert the black probe into the COM end, and the red probe into the mA input end.

(3) The red and black probes are connected to the measured capacitance, and the meter screen displays the measured value.

4.6 Frequency measurement

(1) Select the frequency function in Hz.

(2) Insert the black probe into the COM end and the red probe into the V input end.

(3) The red and black probes contact the tested line, and the meter screen displays the measured value.

4.8 Cancel the automatic shutdown function

(1) Turn off the power. Press the SEL key and turn on the symbol in the upper left corner of the display.Meanwhile, the meter sounds five times, the automatic shutdown function is cancelled, and the function is resumed after it's shut down and restarted again.

5.How to use

5.1 AC voltage measurement

(1) Select the appropriate position in V ~ voltage.

(2) Insert the black probe into the COM end and the red probe into the V input end.

(3) The red and black probes contact the tested line, and the meter screen displays the measured value.

5.2 DC voltage measurement

(1) Select the appropriate position in mV or V according to the corresponding voltage when using.

(2) During measurement of AC voltage, the screen displays the frequency of the AC voltage, and the unit is Hz.

(3) The maximum input voltage of AC voltage is AC 750V(NCV:1V).

(4) As the mV range of DC voltage, due to the interference of electromagnetic field in the use environment, the meter will have a certain number jumping, which is normal as a normal phenomenon. If the probe is not kept in inserted. If the probe is used to shortcircuit the "V" input end and the "COM" end, the meter display will return to zero, which is regarded as a normal phenomenon.

Notes

- Select the suitable position mV or V according to the corresponding voltage when using.
- The maximum input voltage of DC voltage range is DC 1000V.
- As the mV range of DC voltage, due to the interference of electromagnetic field in the use environment, the meter will have a certain number jumping, which is normal as a normal phenomenon. If the probe is used to shortcircuit the "V" input end and the "COM" end, the meter display will return to zero, which is regarded as a normal phenomenon.

5.3 Resistance measurement

(1) Turn the range knob to "Ω" and set.

(2) Short press SEL key to switch to ⏚ resistance position.

(3) Insert the black probe into the COM end, and the red probe into the Ω input end.

(4) The red and black probes are connected to the measured resistance, and the meter screen displays the measured value.

Notes

- To avoid damage to the instrument or equipment under test, cut off the power supply and discharge all high-voltage capacitors before the resistance.
- The measured resistance on the circuit will be different from the actual resistance, because there will be some error between the measured resistance and the resistance components connected in series or in parallel and the actual resistance.
- When the meter is open or the measured resistance value is too large, "OL" will be displayed to indicate that the measured value is out of range.

5.4 On-off measurement

(1) Turn the range knob to "))) " and set.

(2) Short press SEL key to switch to))) on and off position.

(3) Insert the black probe into the COM end, and the red probe into the))) ⏚ input end.

(4) The red and black probes are connected to the tested line.

Notes

During on/off measurement, when the resistance is less than about 50Ω, the circuitry buzzer sounds continuously.

5.5 Diode measurement

(1) Turn the range knob to "➡" diode position.

(2) Short press SEL key to switch to ➡ diode position.

(3) Insert the black probe into the COM end, and the red probe into the ➡ input end.

(4) The red and black probes are connected to the diode under test, and the meter displays the measured voltage value.

Notes

- During the normal diode measurement, the meter shows that the forward voltage drop of the diode under test is about 0.5V ~0.8V, and the reverse voltage is non-conductive.
- If the diode is open or the polarity is reversed, "OL" will be displayed.

5.6 Capacitance measurement

(1) Turn the range knob to ⏚) capacitance.

(2) Insert the black probe into the COM end,

and the red probe into the ⏚) input end.

(3) The red and black probes are connected to the measured capacitance, and the meter displays the measured capacitance value.

Notes

When measuring the capacitance, it is necessary to discharge the capacitance fully before measurement to avoid damage to the meter.For capacitance, and it takes a certain time to stabilize the measured data.

5.7 Temperature measurement

(1) Turn the range knob to ℃/℉ temperature, and the meter will automatically enter the temperature measurement function.

(2) Short press SEL key to switch between ℃/℉.

(3) Measurement of K-type thermocouple: Connect the red plug of K-type thermocouple to the ⏚) input end, and the black plug into the "COM" end. The thermocouple probe contacts the object to be measured for measurements.

Notes

If the temperature of the measured environment changes suddenly, it is necessary to wait for a while for the current measuring environment at a constant temperature for about 15 minutes to make accurate measurement.

5.8 AC current measurement

⚠	**If the voltage of the open circuit is over 250V, it' forbidden to measure the current on the circuit.**

(1) Turn the range knob to uA/mA to measure the current.

(2) Press SEL key to switch to AC current mode.

(3) The frequency of the measured current can be displayed synchronously at the AC current measurement.

(4) Insert the black probe into the COM end.

(5) When the measured current is less than 600mA, turn the range knob to uA position for measurement, and insert the red probe into the uA/mA input.

(6) When the measured current is between 600mA and 10A, turn the range knob to A position for measurement, and insert the red probe into the A input end.

Notes

- If the current is unknown, rotate the position to the maximum range, and adjust the corresponding current range according to the measured value.
- Series fuse and correct range position should be used when measuring current, otherwise it will damage the meter and fuse.
- During current measurement, if the measured value is not displayed on the screen, please check whether the fuse is fused. If the fuse is damaged, the fuse of corresponding specification needs to be replaced before it can be used again.

5.9 DC current measurement

⚠	**If the voltage of the open circuit is over 250V, it' forbidden to measure the current on the circuit.**

(1) Turn the range knob to uA/mA to measure the current.

(2) Press SEL key to switch to DC current mode.

(3) Insert the black probe into the COM input.

(4) When the measured current is below 600mA, turn the range knob to uA position for measurement, and insert the red probe into the uA/mA input.

(5) When the measured current is between 600mA and 10A, turn the range knob to A position for measurement, and insert the red probe into the A input end.

Notes

- If the current is unknown, turn the position to the maximum range, and adjust the corresponding current range according to the measured value.
- Series fuse and correct range position should be used when measuring current, otherwise it will damage the meter and fuse.
- During current measurement, if the measured value is not displayed on the screen, please check whether the fuse is fused. If the fuse is damaged, the fuse of corresponding specification needs to be replaced before it can be used again.

5.10 NCV non-contact AC voltage detection

(1) Turn the range knob to NCV position.

(2) Press SEL key to switch to NCV function.

(3) The detection induction head is at the top of the meter, close the NCV probe of the meter to the conductor, and the corresponding signal indicator lights up according to the intensity of the detection signal. When the induced voltage is AC 90V~1000V, the red indicator lights up, the screen displays H, and when the induced voltage is high, the screen displays H, the red indicator lights up. At the same time, the buzzer sounds different frequencies.

Notes

- Even if there is no indication, the voltage may still exist. Don't rely on NCV detection alone to determine whether the line is charged or not.
- The detection process may be affected by factors such as socket design, different insulation thickness and type.
- Strong electromagnetic interference environment (such as flashlights, motors, electromagnetic interference, etc.) may mistakenly trigger NCV detection.

5.11 Live wire identification

(1) Turn the range knob to the Live position.

(2) Press SEL key to switch to the Live function.

(3) The detection induction head is at the top of the meter, close the (Live) input end, the black probe is pulled out, and the tip of the red probe is inserted into the power jack. If the screen shows «H», red indicator lights up, and the buzzer sounds an alarm, then it's the live wire, otherwise the zero line or the ground line.

Notes

- In the same use, please test on the known live conductor to ensure that the meter is in good working condition.
- For the Live wire identification function, a single red probe is inserted into the input end, and the black probe is pulled out to prevent electric shock!

6. Technical parameters

Working height	Max 2000m
Storage height	12000
Display	LCD
Full range overload protection voltage	1000V
Max	5999
Over-range display	OL or -OL
Sampling time	About 300ms/sec
Automatic shutdown	About 20 minutes
Backlight	Automatic shutdown in about 2minutes
Flashlight	Automatic shutdown in about 5minutes
Power	2x1.5V AA batteries
Low battery	LCD displays "BAT"
Working temperature	0°C - 50°C
Working humidity	0 - 80%RH
Working temperature	-20 - 60°C
Storage humidity	0 - 80%RH
Size	184x88x54mm
Weight	About 300g（excluding batteries）

7. Technical indicators

7.1 DC voltage

Measuring range	Resolution	Accuracy
600mV	0.1mV	±(0.5% reading +5 digits)
6V	0.001V	
60V	0.01V	±(0.8% reading +5 digits)
600V	0.1V	
1000V	1V	±(1.0% reading +5 digits)

Input impedance: 10MΩ / maximum input voltage: 1000V

7.2 AC voltage

Range	Resolution	Accuracy
600mV	0.1mV	±(1.2% reading +5 digits)
6V	0.001V	
60V	0.01V	±(1.2% reading +5 digits)
600V	0.1V	
750V	1V	

Input impedance: 10MΩ

Maximum input voltage: 750V

frequency response: 40Hz~1kHz

7.3 Resistance

Range	Resolution ratio	Accuracy
600Ω	0.1Ω	±(0.8% reading +3 digits)
6kΩ	0.001kΩ	
60kΩ	0.01kΩ	±(0.8% reading +3 digits)
600kΩ	0.1kΩ	
6MΩ	0.001MΩ	±(1.2% reading +5 digits)
60MΩ	0.02MΩ	

Overload protection: 1000V / open circuit voltage: 0.3V~1V

7.4 Diode

Function	Range	Resolution ratio	Test condition
Diode test	0.7V-3V	0.001V	Forward DC current: about 2mA Open circuit voltage: about 3V

Overload protection: 1000V

7.5 On-off test

Function	Range	Resolution	Description	Test condition
)))	600Ω	0.1Ω	When the resistance is less than about 50Ω, the built-in buzzer sounds continuously.	Open circuit voltage about 0.5V, short-circuit current about 0.5 mA

Overload protection: 1000V

7.6 Capacitance

Range	Resolution	Accuracy
6nF	0.001nF	±3.5% reading +15 digits)
60nF	0.01nF	
600nF	0.1nF	
6uF	0.001uF	
60uF	0.01uF	±4.0% reading +20 digits)
600uF	0.1uF	
6mF	0.001mF	
60mF	0.01mF	±4.0% reading +20 digits)

Overload protection: 1000V

7.7 Temperature

Range	Resolution	Accuracy
-20~1000℃	1℃	±(2.0% reading +2 digits)
-4~1832℉	1℉	±(2.0% reading +4 digits)

Overload protection: 1000V

7.8 DC current

Range	Resolution	Accuracy
600uA	0.1uA	±(0.8% reading +5 digits)
6000uA	1.0uA	
60mA	0.01mA	±(1.2% reading +3 digits)
10A	0.01A	

Overload protection

mA range fuse (FF600mA/1000V)

10A range fuse (FF10A/1000V)

7.9 AC current

Range	Resolution	Accuracy
600uA	0.1uA	±(1% reading +5 digits)
6000uA	1.0uA	
60mA	0.01mA	±(1.2% reading +5 digits)
10A	0.01A	

Overload protection

mA range fuse (FF600mA/1000V)

10A range fuse (FF10A/1000V)

Frequency response: 40Hz~1kHz

8. Battery replacement

⚠	In order to avoid electric shock or personal injury caused by misoperation, the meter should be turned off and disconnected when the " " symbol appears on the instrument display. Before opening the battery cover to replace the battery, the meter should be turned off and disconnected from the measuring circuit.

1. Turn off the power supply.
2. Remove the test probe from the measuring circuit.
3. Use a screwdriver to unscrew the battery cover screw on the back of the instrument.
4. Remove the battery cover.
5. Replace with a new 1.5V/AA battery.
6. Replace with a new 1.5V/AA battery.
7. Install the battery cover and tighten the fixing screws.

9.Accessories

1. Multimeter	One
2. Manual instruction	One
3. Probe	A pair
4. K-type temperature probe	One
5. 1.5x2 AA battery	A pair