USERS MANUAL

Made in China

CE RoHS M101040052

Before using the instrument, please read this manual carefully and save it well for future using.

USERS MANUAL

Digital multimeter



120*90mm

Overview/Safety information

1.Overview

The DM2000 is a 4000-count and auto-range digital multimeter with MAX maximum hold, HOLD data hold, temperature measurement, automatic shutdown, backlight, full range overload protection and battery undervoltage indication functions. It is widely used in industrial and mining, instrument lovers or families, it is an ideal multifunctional product.

-The instrument can be used to measure AC/DC voltage, AC/DC current, resistance, capacitance, diode, on/off test, temperature, live wire identification and NCV non-contact AC voltage detection.

2.Safety information

⚠ Attention should be paid to the use of the instrument. Wrong operation may cause damage to the instrument or danger to it. Please read the instructions carefully before using, and use the instrument according to the operating instructions.

-Please read the following safety information carefully before operating the instrument, please check whether it is damaged during transportation and whether the probe is in good condition.

-During use, please check whether the instrument shell is damaged, whether the insulation layer of the probe complete and whether the wire is exposed.

-It is forbidden to measure beyond the indicated value of the range protection range, and to switch positions during measurement.

-When measuring voltage exceeding 36V DC or 25V AC rms, the finger must be in the safe area of the protection device of the probe sheath, and it is forbidden to touch the probe tip (metal part).

-When measuring voltage above 1000V DC or 700V AC (effective value), please be careful, and the maximum voltage measured at COM end and V input end shall not exceed AC 800V/DC 1000V.

-When changing the measuring function, please remove the probe from the circuit under test.

Sys/Maintenance

2.1 Signs

⚠	Warning! For important safety information, please refer to the instruction manual before use.
⚠	Pay attention to the safety of use in case of electric danger!
⧈	Double insulation protection (Class II)
⎓	DC
⏦	Fuse
CE	Comply with the standards of the European Community (EU)
CAT III	Refers to the level of pulse withstand voltage protection provided by overvoltage (installation) level III and pollution degree 2 according to IEC-61010 standard

2.2 Maintenance

-Non-professional maintenance personnel are forbidden to open the bottom case to adjust or repair the instrument.

-Store the instrument in a dry place away from high temperature, humidity, corrosive gases and pollution.

-If the instrument is stained with dirt or dust, please clean it with a soft cloth.

-Do not use abrasive or flammable solvents to clean it.

-If the instrument is stored for a long time, the battery should be taken out to prevent leakage and corrosion.

Schematic diagram of appearance

3.Instrument introduction

3.1 Schematic diagram of appearance



1. NCV non-contact AC voltage detection probe
2. LCD display
3. Function keys
4. Range knob
5. Input end

Input end/Display symbol

3.2 Description of input end

Input end	Description
COM	Common input end (connected with black probe)
VΩ-Hz-Ln/NCV +TC/mA/μA/mA	Voltage, resistance, capacitance, temperature diode, on/off test, live wire identification, and input end of current measurement (connected with red probe)
10A	Input end of current 10A (connected with red probe)

3.3 Description of display symbol

Symbol	Description
AUTO	Battery undervoltage indicator
	Automatic shutdown function
-	Negative electricity
≂	AC voltage
⎓	DC voltage
⏻	On/off test
⏾	Backlight
°C/°F	°C/°F
HOLD	Data hold
MAX	Maximum hold
NCV	Non-contact AC voltage detection
Ln	Live wire identification
Hz	Frequency
mV/V	Voltage
Ω/K/M	Resistance
nF/uF/mF	Capacitance
uA/mA/A	Current

Key Description/Operation guide

3.4 Key Description

Key	Description
HOLD	Data hold
MAX	Maximum hold
☀	Backlight
SEL	Function selection key

4. Operation guide

4.1 Data hold

HOLD key: short press can lock the measurement data, and short press the HOLD key again to unlock it.

4.2 MAX maximum hold

The maximum value can be saved at AC/DC voltage position, AC/DC current position and resistance position to hold the maximum value of measured data, and short press to turn this function on or off.

4.3 On/off test

Long press Fn( ) key to turn on or off the backlight.

4.4 SEL function selection key

The instrument performs function selection at AC/DC mV position, resistance position, on/off position, diode position and temperature position. Long press SEL key to enter this position.

4.5 Automatic shutdown function

If there is no operation after about 20 minutes of powerup, the instrument will automatically shut down and enter a dormant state. Press the (SEL) key to restart the machine.

AC voltage/DC voltage

5. How to use

5.1 AC voltage measurement

(1) Turn the range knob to ( ) AC voltage position.

(2) Insert the black probe into the COM end and the red probe into the V input end.

(3) Move the red and black probes to the tested line, and the instrument screen displays the measured value.

Note

① Choose appropriate position mV or V according to the corresponding voltage.

② During measurement of AC voltage, short press the HZ key and then the screen displays the frequency of the measured voltage.

③ The instrument has a built-in resistance of about 2MΩ(NCV=3kΩ)

④ For the mV range of AC voltage, even if there is no input or insertion of the probe, the instrument will have a numerical display, because of the induction of the surrounding electric field on the input end. At this moment, yes, when the "V" input end and the "COM" end is under short circuit by a probe.

5.2 DC voltage measurement

(1) Turn the range knob to ( ) DC voltage position.

(2) Insert the black probe into the COM end and the red probe into the V input end.

(3) Move the red and black probes to the tested line, and the instrument screen displays the measured value.

Note

① Choose appropriate position mV or V according to the corresponding voltage.

② The maximum input voltage of DC voltage position is DC 600V.

③ For the mV range of DC voltage, even if there is no input or insertion of the probe, the instrument will have a numerical display, because of the induction of the surrounding electric field on the input end. At this moment, yes, when the "V" input end and the "COM" end is under short circuit by a probe.

Resistance/On-off test

5.3 Resistance measurement

(1)Turn the range knob to " " resistance position.

(2)Short press the SEL key to switch to (kΩ) resistance position.

(3) Insert the black probe into the COM end, and the red probe into the (Ω) input end.

(4) Connect the red and black probes to the measured resistance, and the measured value is displayed on the instrument screen.

Note

① In order to avoid the damage of the instrument or the equipment under test, when measuring the resistance, cut off the power supply of the equipment under test and discharge all high-voltage capacitors.

② The measured value on the circuit may be different from the actual one, and there will be some errors between them, because other circuits connected to the measured circuit will affect it.

③ When the instrument is open or the measured resistance value is too large, "OL" will be displayed to indicate that the measured value is out of range.

5.4 On-off test

(1)Turn the range knob to " " on-off position.

(2) Short press the SEL key to switch to " " on-off position.

(3) Insert the black probe into the COM end, and the red probe into the (Ω) input end.

(4) Connect the red and black probes to the tested line.

Note

During on-off measurement, if the resistance is less than about 50Ω, the instrument emits a buzzer.

Diode/Capacitance/Temperature

5.5 Diode measurement

(1) Turn the range knob to " " diode position.

(2) Short press the SEL key to ( ) diode position.

(3) Insert the black probe into the COM end, and the red probe into the ( ) input end.

(4) Connect the red and black probes to the diode, the instrument screen displays the forward voltage value of the diode under test.

Note

Having measurement of a normal diode, the instrument displays the forward voltage drop value of the diode under test is about 0.5V~0.8V, but it is not conductive in the reverse direction.

5.6 Capacitance measurement

(1) Turn range knob to ( ) capacitance position.

(2) Insert the black probe into the COM end, and the red probe into the ( ) input end.

(3) Connect the red and black probes to the measured capacitance, and the instrument displays the measured capacitance value.

Note

① Before measurement of the capacitance, discharge the capacitance. It will take some time to stabilize the measured data.

5.7 Temperature measurement

(1) Turn the range knob to the temperature position ( ), and the instrument will automatically measure the current ambient temperature.

(2) Short press SEL key to switch to (°C/°F).

(3) Kntpe thermocouple measurement: Connect the red plug of K-type thermocouple to the "TC" and "COM" jacks, and the red is "TC" and black is "COM", and move the thermocouple probe to the measured object for measurement.

AC current

Note

If the temperature of the measured environment suddenly changes, the instrument should be placed in the current measuring environment for more than 1 hour to adapt to the ambient temperature for accurate measurement.

5.8 AC current measurement

⚠ **When the open circuit voltage is 250V, do not measure the current on the circuit.**

(1) Turn the range knob to uA/mA/A position.

(2) Press the SEL key to AC current function.

(3)Short press the H2 key at the AC current key, and the frequency of the measured current will be displayed.

(4)Insert the black probe into the COM input.

Measured value	Range	Input end connected by the red probe
0uA~4000uA	uA	uA/mA
4000uA~4000uA	mA	
4000mA~10A	10A	10A

Note

① If the current is unknown, first turn the position to the maximum range, and adjust the corresponding current range according to the measured value.

② Use the same band are the correct range position for current position measurement and over-range measurement is forbidden.

③ The instrument is protected by a fuse, and the fuse will not be blown, check whether the fuse is blown. If the fuse is damaged, replace it with a new one with the corresponding specification before use.

DC current

5.9 DC current measurement

⚠ **When the open circuit voltage is 250V, do not measure the current on the circuit.**

(1) Turn the range knob to uA/mA/A position.

(2) Press the SEL key to DC current function.

(3) Insert the black probe into the COM input.

Measured value	Range	Input end connected by the red probe
0uA~4000uA	uA	uA/mA
4000uA~4000uA	mA	
4000mA~10A	10A	10A

Note

① If the current is unknown, first turn the position to the maximum range, and adjust the corresponding current range according to the measured value.

② Use the same band are the correct range position for current position measurement and over-range measurement is forbidden.

③ The instrument is protected by a fuse, and the fuse will not be blown, check whether the fuse is blown. If the fuse is damaged, replace it with a new one with the corresponding specification before use.

NCV/Live wire identification

5.10 NCV non-contact AC voltage detection

Live wire identification

(1)Press the SEL key to NCV function.

(2) When the screen displays the NCV symbol, close the NCV probe to the measured object, and when the induced voltage is low, the screen displays L, and when the induced voltage is high, the screen displays H, and the buzzer sounds alarms at different frequencies.

Note

① Even if there is no indication, voltage may still exist. Don't rely on non-contact voltage detection to judge whether there is voltage on the conductor ② The detected process may be influenced by factors such as socket structure, insulation thickness, etc.

③ Interference from external environment (such as flashlights, motors, electromagnetic interference, etc.) may trigger noncontact voltage detection alarms.

5.11 Live wire identification

(1)Turn the range knob to the Live position.

(2)Press the SEL key to Live function.

(3)Insert the single red probe into the input end (Live), unplug the black probe, touch the metal part of the measured wire with your finger, the display shows H, the buzzer sounds an alarm, then it's identified as a live wire, or else neutral wire or earth wire.

Note

① Before use, please test on the known live conductor to ensure that the instrument is working properly.

② When using the Live wire identification function, insert a single red probe into the input end (Live), and pull out the black probe to prevent the risk of electric shock!

Technical parameters

6. Technical parameters

Operating height	Max 2000m
Manual range	Yes
Display	LCD
Full range overload protection	250V
Maximum display	3999
Over-range indication	OL or -OL
Sampling time	About 3 time/sec
Automatic shutdown	About 20 minutes
Backlight	About 2 minutes to shut down
Power	2x1.5V AAA battery
Low battery	LCD display ▮ symbol
Operating temperature	0°C~50°C
Operating humidity	0~85%RH
Storage. temperature	-20~60°C
Storage humidity	0~80%RH
Size	194x73x32mm
Weight	About 146g(excluding the battery)

DC voltage/AC voltage

7.Technical indicators

7.1 DC voltage

Range	Resolution	Accuracy
400mV	0.1mV	±(1.2% reading +5 digits)
4V	0.001V	
40V	0.01V	±(0.5% reading +5 digits)
400V	0.1V	
600V	1V	±(0.8% reading +5 digits)

Engangementpanel: 10MΩ

Maximale Eingangsspannung: 600V

7.2 AC voltage

Range	Resolution	Accuracy
400mV	0.1mV	±(1.0% reading +5 digits)
4V	0.001V	
40V	0.01V	±(1.2% reading +5 digits)
400V	0.1V	
600V	1V	

Input impedance: 10MΩ

measure range: 40Hz~1kHz

frequency response: 40Hz~1kHz

Resistance/Diode/On-off test

7.3 Resistance

Range	Resolution ratio	Accuracy
400Ω	0.1Ω	±(1.2% reading +5 digits)
4kΩ	0.001KΩ	
40kΩ	0.01KΩ	
400kΩ	0.1KΩ	
4MΩ	0.001MΩ	±(1.5% reading +5 digits)
40MΩ	0.01MΩ	

Overload protection: 250V

open circuit voltage: 1V

7.4 Diode

Function	Range	Resolution ratio	Test condition
Diode test	0.1V~2V	0.001V	Forward open circuit voltage about 2V, current about 1mA

Overload protection: 250V

7.5 On-off test

Function	Range	Resolution	Description	Test condition
On-off test	600Ω	0.1Ω	If the resistance is less than about 50Ω, the buzzer will beep.	Open circuit voltage about 0.5mA

Overload protection: 250V

Capacitance/Temperature/DC current

7.6 Capacitance

Range	Resolution	Accuracy
40nF	0.01nF	±(3.5% reading +15digits)
400nF	0.1nF	
4uF	0.01uF	
40uF	0.1uF	
4mF	0.001mF	±(4.0% reading +20 digits)

Overload protection: 250V

7.7 Temperature

Range	Resolution	Accuracy
-20~1000°C	1°C	±(2.0% reading +2 digits)
-4~1832°F	1°F	±(2.0% reading +4 digits)

Overload protection: 250V

7.8 DC current

Range	Resolution	Accuracy
4000uA	1uA	±(1.0% reading +3 digits)
4000mA	0.1mA	±(1.2% reading +5digits)
10.00A	0.01A	

Overload protection: mA range fuse (FF600mA/250V),10A range fuse (FF15A/250V).

AC current/Battery replacement/Accessories

7.9 AC current

Range	Resolution	Accuracy
4000uA	1uA	±(1% reading +3 digits)
4000mA	0.1mA	±(1.2% reading +5 digits)
10.00A	0.01A	

Overload protection: mA range fuse (FF600mA/250V),10A range fuse (FF15A/250V).

8. Battery replacement

⚠ **In order to avoid electric shock or personal injury caused by misoperation, the battery cover must be opened immediately when the " " symbol appears on the instrument display.Before opening the battery cover to replace the battery, please ensure that the test probe has been disconnected from the measuring circuit.**

① Turn off the power supply.

② Remove the test probe from the measuring circuit.

③ Use a screwdriver to remove the screw of the battery cover.

④ Take out the battery and replace it with a new battery.

⑤ Replace with a new 1.5SEAAA battery.

⑥ Install the battery cover and tighten the fixing screws.

9. Accessories

1. Multimeter	One
2. Manual instruction	One piece
3. Fuse	A pair
4. K-type temperature probe	A pair
5. 1.5V AAA battery	Two pieces